

Step One **Remove**

- A** Remove existing thru axle from bike.
- B** Remove UDH drive side locking bolt.



Step Two **Install**

- C** Install Tailfin UDH Converter. Include 30mm washer for ABP bearing seals. Tighten to 25Nm.
- D** Optional. Use 12mm to 8mm hex key converter. Keep with your multi tool out on your rides.
- E** Install Tailfin M12 x 1.0 Thru Axle. Tighten to 10Nm.

